




INSTALLING TEMPLATES

1. Find and print the template for the song you want. Your printer must be set to print original size without reduction or enlarging. Then cut the template out as shown on the right. Be careful not to cut off tabs. 

For best fit cut off all the white paper around the template.

2. Remove plastic overlay that allows fingers to feel the area where keys are located. Take note that one of the tabs is smaller than the other tabs and must be placed in the slot near the octave changing switch when plastic overlay is replaced. 

3. Install template by placing tabs in the slots as shown here. Make sure the red arrow points to the "ON" light. You can play song without overlay, but template may move and the position of the key can no longer be located by finger searching or touch. 

4. Replace plastic overlay. Make sure that the small overlay tab is in the slot near octave changing switch. Now only the keys for the song on the template are shown, making notes easier to find and songs easier to play. 